

# NORITSU PROFILE FOR MG-1000 Mitsubishi Grace Paper

## Printing condition setting

### A. Analog printing machine

Change the emulsion number as for a normal paper lot change. (With the MG-1000, cyan sensitivity is higher than that with the SA-H, so it will print slightly deeper blue under the same conditions.). Then, after changing the emulsion number, slope adjustment is performed if yellow-green remains (over/under).

### B. Digital printing machine

#### Noritsu minilab system

- (1) When changing the paper lot, change the emulsion number for the sizes that have been changed to MG-1000.
- (2) After all paper sizes are switched to MG-1000, upgrade the profile and main program for MG-1000 (if not the latest version) and perform initial setup

#### Profile for MG-1000

Profile data: Profile Data Vol.2 Ver.7.02 (Noritsu QSS-2901 to 3501)

The main program must be the following version or newer. If it is an older version, upgrade along with the profile.

Main program : Noritsu QSS-29**	Version J001
Noritsu QSS-30**	Version J001
Noritsu QSS-3101· 3101-1· 3111· 3111-1· 31PRO· 31PRO-1	Version G001
Noritsu QSS-3102· 31PRO TURBO	Version 3.00
Noritsu QSS-3102-2· 3112-2	Version 4.00
Noritsu QSS-32**· 32**PRO	Version 8.00
Noritsu QSS-32**SD· 32**SD PRO	Version 4.00
Noritsu QSS-33**· 33**PRO	Version 7.00
Noritsu QSS-3300iBeam	Version 4.00
Noritsu QSS-33**SD· 33SD PRO	Version 6.00
Noritsu QSS-3411· 34**PRO	Version 5.00
Noritsu QSS-3501· 3502· 3501	Version 3.0

\*Request Noritsu or a Noritsu agent to upgrade the profile and main program