

AGFA D-LAB

Switching to Mitsubishi Paper MG-1000 Series

For each paper size and surface you have to use the following procedure

Go to Menu [Test] [start MBL]

Activate the check-box “with Laser Point”

Change the values for Dmax red (2.4) Dmax green (2.2) en Dmax blue (2.1)

Change the Cal factor red (0.97) Cal factor green (0.95)

Cal factor blue (0.99)

Start the calibration by clicking on the [Start]

These settings can be used as starting point for adjusting the printer settings

This screenshot is an example; the showed information is not the same as the above correct instructions

